

TABLE OF CONTENTS

INTRODUCTION	3
PRE-TRAVEL CHECK LIST	4
EXTERIOR	4
INTERIOR	4
RULES FOR EQUIPMENT SELECTION AND PREPARATION FOR TOWING	4
ON THE ROAD	5
TRAVEL TRAILER & 5 TH WHEEL TRAILER LOADING	5
DETERMINING AND DISTRIBUTING THE TRAILER'S LOAD	6
HITCHING UP YOUR TRAILER	6
GENERAL	6
HITCHING PROCEDURE FOR CONVENTIONAL TRAILERS	6
HITCHING PROCEDURE FOR 5 th WHEEL TRAILERS	7
THE BRAKING SYSTEM	8
BRAKE SYSTEM COMPONENTS	8
BRAKING TIPS	10
TOWING SPEED	10
LIFE WITH YOUR NEW TRAILER	11
ENTRY STEP	11
ENTRY ASSIST HANDLE	11
ENTRY DOORS, SCREENS, AND LOCKS	11
WINDOWS:	11
EMERGENCY EXIT WINDOW	11
EXTERIOR COMPARTMENTS	11
DINETTE CONVERSION	12
OPERATING THE SLIDE OUT ROOM	12
EXTENDING THE SLIDE OUT ROOM	12
CLOSING THE SLIDE OUT ROOM	12
FRESH WATER SYSTEM	13
EXTERNAL HOOKUP	13
SELF-CONTAINED WATER SYSTEM	13
FRESH WATER FILL INSTRUCTIONS	14
SANITIZING THE FRESH WATER SYSTEM	14
ELECTRIC 12-VOLT DC WATER PUMP	15
THE MONITOR PANEL	15
WASTE WATER SYSTEM	15
DUMPING THE HOLDING TANKS	16
HOLDING TANK CARE AND MAINTENANCE	17
TOILET	17
ELECTRICAL SYSTEMS	17
CHASSIS ELECTRICAL SYSTEM	17
BATTERY CHARGING	18
120-VOLT AC SYSTEM	18
THE POWER CENTER	18
GROUND FAULT INTERRUPTER	18
LPG (LIQUEFIED PETROLEUM GAS) SYSTEM	19
LP GAS APPLIANCES)	19
LPG TANKS	19
LP GAS PRESSURE REGULATOR	19
VENTING	19
FILLING LP GAS TANKS	19
LPG TANK INSTALLATION	20
START-UP and OPERATION OF LP GAS APPLIANCES	20
LPG SAFETY PRECAUTIONS	20
USING LP GAS SYSTEM AT LOW TEMPERATURES	21

APPLIANCES and EQUIPMENT	21
LP GAS (LPG) LEAK DETECTOR	21
FURNACE	22
WATER HEATER	22
GENERATOR (optional equipment)	22
GENERATOR POWER SWITCH	22
RANGE TOP BURNER AND OVEN	22
REFRIGERATOR	23
SMOKE DETECTOR	23
FIRE EXTINGUISHER	23
CARBON MONOXIDE (CO) DETECTOR	23
POWER RANGE EXHAUST HOOD	23
MICROWAVE OVEN (option)	23
ROOF MOUNTED AIR CONDITIONER (option)	23
FANTASTIC VENT (option)	23
A/M F/M STEREO TAPE OR CD PLAYER (option)	24
TV ANTENNA (option)	24
OTHER ESSENTIAL INFORMATION	24
WINTER PROTECTION	24
WINTER PROTECTION WHILE TRAILER IS IN USE	24
PREPARING FOR LONG-TERM STORAGE	24
DRAINING THE WATER SYSTEM	24
WINTERIZING WITH NON-TOXIC ANTIFREEZE	25
SEMI-AUTOMATIC WINTERIZATION SYSTEM	25
OUTDOOR WINTER STORAGE INSTRUCTIONS	26
EXTERIOR	26
INTERIOR	26
EXTERIOR MAINTENANCE	26
EXTERIOR FINISH	26
SIGNS OF WEATHERING	26
WINDOWS, DOORS, VENTS AND LOCKS	27
SEALANT RENEWAL	27
DOORS AND WINDOWS	27
RUBBER ROOF	28
INTERIOR MAINTENANCE	28
UPHOLSTERY AND WINDOW TREATMENT	28
WALL AND CEILING PANELS	28
FLOORS AND CARPETING	28
TUB AND SHOWER	28
WOOD PRODUCTS	28
LAMINATE COUNTER TOPS AND TABLE	29
GENERAL INFORMATION AND HELPFUL HINTS	29
NOTICE TO CAMPERS	29
SYMPTOMS OF CARBON MONOXIDE POISONING	29
EMERGENCY LIFESAVING TREATMENT FOR CARBON MONOXIDE POISONING	29
CONDENSATION AND YOUR RV	29
DUST SEEPAGE	31
SAFE DRIVING TIPS	31
TRAVELING SPEED	31
OTHER TRAVELING TIPS	31
SAFETY CONSIDERATIONS	33
SAFETY REGULATIONS REGARDING LP GAS	34
PRODUCT IDENTIFICATION INFORMATION	35
APPLIANCE AND PRODUCT OWNER'S MANUALS	36
PERIODIC MAINTENANCE CHECK LIST	38
SERVICE CHART	39
WARRANTY	40

INTRODUCTION

Welcome to the family of NORTHWOOD recreational vehicle owners. We thank you for selecting a NORTHWOOD product.

Your new NORTHWOOD travel trailer or 5th wheel trailer has been designed to provide carefree traveling for you and your family. This Owner's Manual provides helpful suggestions and useful information to help you get maximum enjoyment from your new trailer.

Similar to your automobile, your trailer will require some regular care before each use plus some annual maintenance. This manual is structured to equip you with a good working knowledge of your new trailer. We at NORTHWOOD want you to know what needs to be done and how to correct and prevent minor difficulties.

NORTHWOOD recommends that you become familiar with the contents of this Owner's Manual before using your trailer. Every effort has been made to make this Owner's Manual as accurate as possible. Products are constantly being improved and manufacturers upgrade installations accordingly. In the event of conflicting instructions, illustrations or other descriptions, the information furnished by the respective manufacturer's separate publications should be followed.

Your new trailer has been constructed to conform with or exceed federal and state safety requirements. Quality assurance methods and/or functions meet or exceed standards prescribed by ANSI/NFPA 501C or CSA Z240 as approved by the agency having jurisdiction in the United States or Canada.

Please contact your dealer should you have any additional questions as to operation, maintenance or service.


PRE-TRAVEL CHECK LIST

● EXTERIOR

- Disconnect water, electrical, and drain lines.
- Check roof top carrier (if installed).
- Remove blocks from wheels. Retract steps.
- Close front window and lower rockguard.
- Check wheel nut torque. (See diagram below)
- Check LPG tank level and refill if necessary.
- Check hitch and hitch ball.
- Check tires and adjust pressures if necessary.
- Check batteries.
- Check running lights, turn signals, interior and panel lights.
- Check brakes, brake fluid, brake lights.
- Proper hitching procedure.
- Check cooling system.
- Lock deadbolt in entry door(s).

● INTERIOR

- Lower TV antenna.
- Turn off water heater.
- Turn off water pump.
- Turn off furnace.
- Turn off range pilot.
- Close cooktop cover.
- Close roof vents.
- Close all doors, drawers and windows.
- Secure freestanding furniture.



RULES FOR EQUIPMENT SELECTION AND PREPARATION FOR TOWING

Your towing equipment, its adjustments and how you load the trailer will have a great effect on trailer towing stability and handling. The following rules will help you select, adjust and load your equipment in a manner that will help produce acceptable towing characteristics:

1. Use a tow vehicle that is large enough for your trailer and has the needed power and heavy duty running gear. The tow vehicle must be rated by its manufacturer both to tow the gross weight and to carry the hitch weight of the fully loaded trailer.
2. Use a weight distributing hitch rated not less than the trailer Gross Vehicle Weight Rating (GVWR). Follow the tow vehicle and hitch manufacturer's instructions. Install the hitch ball as

close as practical to the rear bumper to minimize rear overhang.

3. Use a sway control system, installed and adjusted according to the sway control manufacturer's instructions.
4. Use a brake controller that automatically applies the brakes in proportion to the tow vehicle brakes.
5. Adjust the brake controller so that the brakes of the trailer operate as quickly as possible without sliding the tires of the loaded trailer during strong braking.
6. Do not use an automatic speed control while towing.
7. Inflate the rear tires of the tow vehicle to their maximum cold pressure.
8. Inflate the trailer tires to their maximum cold pressure.
9. Load the trailer placing heavy objects and goods as close to the trailer axle(s) as possible. Do not place heavy objects on the rear bumper or on the tongue.
10. Adjust the hitch ball height so that the fully loaded trailer is level front-to-rear when attached to the fully loaded tow vehicle with the hitch spring bars tightened.
11. When loading the trailer do not exceed the trailer Gross Axle Weight Rating(s) (GAWR). Weigh the fully loaded trailer from time to time to verify that trailer GAWR and GVWR are not exceeded, and that the loads on the right-hand and left-hand wheels are approximately equal.
12. Do not exceed the tow vehicle Gross Axle Weight Ratings(s) (GAWR) or Gross Vehicle Weight Rating (GVWR). Weigh the tow vehicle from time to time to verify these loadings.

ON THE ROAD

TRAVEL TRAILER & 5TH WHEEL TRAILER LOADING: A trailer chassis (springs, wheels, tires, axles, frame and tongue) is designed to carry a certain maximum load. This load consists of the weight of the empty trailer itself, and weight added in the form of water, food, clothing, and anything else that may be stored in or attached to the trailer. The maximum load for which the trailer is designed is called the **GROSS VEHICLE WEIGHT RATING (GVWR)** and is the total of the weight on the axles and the weight on the trailer tongue.

Another critical weight factor is the **GROSS AXLE WEIGHT RATING (GAWR)**. This is the maximum weight a specific axle is designed to carry. Again the rating represents the empty vehicle's axle weight plus the added load. On trailers with more than one axle, the weight is divided between each axle and each has its own **GAWR**. The total of all axle loads plus the tongue weight must not exceed the trailer **GVWR**.

Tongue weight is the amount of pressure exerted downward on the hitch ball. Your trailer is designed for maximum tongue weight and hitch tongue weight ratings.

WARNING: DO NOT EXCEED THE SPECIFIED TONGUE WEIGHT AS YOU

COULD CAUSE DAMAGE TO THE TRAILER FRAME. ALSO, OVERLOADING COULD RESULT IN POOR HANDLING AND BRAKING.

DETERMINING AND DISTRIBUTING THE TRAILER'S LOAD: The **GROSS VEHICLE WEIGHT RATING (GVWR)** for your trailer is found on the label attached at the front road side of the trailer. You must compare the **GVWR** to the actual loaded weight of your trailer. If the loaded weight of your trailer exceeds the **GVWR**, your trailer is overloaded and you will have to remove items to bring the weight down to or below the **GVWR**.

WARNING: DO NOT EXCEED THE RATED LOAD OF THE TOW VEHICLE, THE TRAILER, OR THE RATED LOAD OF ANY AXLE.

NOTE: IF OTHER EQUIPMENT OR OPTIONS SUCH AS LEVELING JACKS, AWNINGS, ROOF STORAGE PODS, ETC., ARE INSTALLED AFTER THE TRAILER LEAVES THE FACTORY, THE WEIGHT OF THESE ITEMS MUST BE SUBTRACTED FROM THE TOTAL OF THE LOAD AND CARGO CARRYING CAPACITIES.

WARNING: DO NOT INSTALL ANY TYPE OF WEIGHT CARRYING RACK, FRAME, OR HITCH TO THE REAR BUMPER, FRONT A-FRAME ASSEMBLY, CHASSIS OR BODY COMPONENT OF THE TRAILER. DAMAGE TO THE TRAILER BODY AND UNSTABLE HANDLING CHARACTERISTICS MAY RESULT. ADD-ONS TO THE REAR BUMPER, FRONT A-FRAME ASSEMBLY OR CHASSIS WILL VOID YOUR WARRANTY ON STRUCTURAL COMPONENTS.

WARNING: DO NOT STORE OR CARRY LP GAS CONTAINERS, GASOLINE, OR OTHER FLAMMABLE LIQUIDS INSIDE YOUR TRAILER.

HITCHING UP YOUR TRAILER

GENERAL: Hitching up your trailer will become routine with experience. Make it a habit to examine all hitch components before hitching up the trailer. If you have a conventional ball hitch, check for cracked or bent parts, cracked welds, deformed or stripped bolts. Inspect the weight-distributing hitch spring bars and chains. Be sure the hitch ball is tight and well lubricated. Check the trailer tongue for cracks. Be sure the ball locking device works freely. Inspect the safety chains. If you find defects in any hitch component, correct it before towing the trailer.

HITCHING PROCEDURE FOR CONVENTIONAL TRAILERS: Before attempting to hitch up your trailer, read the instructions provided by your hitch manufacturer. Your trailer coupler is built for a 2-5/16" hitch ball. **Your hitch ball must be this size.**

The following instructions are usable in most cases. If the instructions provided with your hitch deviate from these instructions, follow the hitch manufacturer's instructions.

1. Turn the tongue jack crank clockwise to raise the tongue and coupler. Raise the tongue sufficiently to clear the hitch ball on the tow vehicle.
2. Back the tow vehicle until the hitch ball is under the hitch ball socket. If you are working alone, a backing aid mirror may be helpful.
3. Be sure the coupler latch locking lever on the tongue is fully open. Lower the tongue jack until

the ball is firmly seated in the socket. Close the coupler latch and secure it with a locking pin or bolt.

4. Raise the tow vehicle and trailer with the tongue jack high enough to allow room to install the weight distributing hitch spring bars.
5. Attach the spring bars according to the weight distributing hitch manufacturer's instructions.
6. After adjusting the spring bars, lower the jack, remove the dolly wheel or foot, and fully retract the jack. Note that the trailer must be relatively level, front to back. Any tilt must be very slight.
7. Install the sway control system according to the manufacturer's instructions.
8. Connect the safety chains. Loop each chain through a suitable attachment eye on the tow vehicle. To adjust the chain length, insert the chain quick coupler through an appropriate chain link.

WARNING: NEVER ATTACH SAFETY CHAINS TO THE HITCH BALL OR ANY REMOVABLE PART OF THE HITCH.

9. Connect the breakaway switch lanyard to an attachment eye on the tow vehicle. Be sure the switch lanyard is adjusted so that the switch is not actuated during a full "jackknife" turn.

WARNING: DO NOT CONNECT THE BREAKAWAY SWITCH LANYARD TO THE HITCH BALL OR ANY REMOVABLE PART OF THE HITCH.

10. Plug in the 12-volt electrical cord into the mating tow vehicle socket.
11. Run an operational check of stop lights, turn indicators, running lights, and electric brakes before driving off. See "ELECTRICAL SYSTEM" for more details about the electrical system and wiring.

HITCHING PROCEDURE FOR 5th WHEEL TRAILERS: Before hitching up your trailer, read the instructions provided by the hitch manufacturer. The following instructions apply in most cases. If the instructions provided with your hitch differ from this procedure, follow the manufacturer's instructions.

Adjust the height of the receiver and trailer pin box so that the loaded trailer is level when hitched to the tow vehicle and ready to travel.

NOTE: CHECK PIN BOX ADJUSTING BOLT TORQUE WITH A TORQUE WRENCH. TORQUE TO 150 FT.-LBS.

The tow vehicle and trailer should be on level ground. This makes connecting the receiver and pin box much easier if both height and side-to-side levels are carefully matched.

1. Raise or lower the front of the trailer so the king pin height matches the coupler assembly of the tow vehicle.
2. Open coupler locking device so the pin will engage the hitch plate jaws.

3. Lower tow vehicle tailgate.
4. Slowly back the tow vehicle toward the pin box until the tailgate can be raised after clearing the king pin. Keep king pin and coupler aligned.
5. Close tailgate.
6. Continue backing and engage king pin and coupler completely.
7. Close coupler locking device. Engage the safety latch.
8. Raise fifth-wheel landing gear.
9. Connect the break away switch lanyard. Make sure the lanyard is adjusted so that the switch is not actuated during a full jackknife turn.
10. Plug the 12-volt electrical cord into the mating receptacle on the tow vehicle.
11. Run an operational check of brake lights, turn signals, running lights, and electric brakes before leaving on your trip.
12. Reverse this procedure for unhitching your trailer.

THE BRAKING SYSTEM


The electric brakes on your trailer are similar to the drum brakes on your car or truck. The basic difference between them is that your trailer brakes are operated by 12-volt direct current from the tow vehicle, rather than by direct hydraulic action. The brakes have been factory calibrated for smooth, positive response. During the break-in period, you may experience squeaking brakes. This is normal and will cease after a few miles of break-in wear.

BRAKE SYSTEM COMPONENTS: The braking system on your trailer consists of several major components, all of which must function properly for safe and responsive braking.

1. **Tow Vehicle Battery:** The tow vehicle is the primary electrical power source for the trailer braking system. The connection is made at the positive post of the battery or at the tow vehicle starter solenoid battery terminal.

2. **Brake Controller:** Note: The brake controller is not supplied with your trailer. The electric trailer brakes are automatically applied by the brake controller, which is usually mounted within easy reach of the tow vehicle driver.

WARNING: DO NOT INSTALL A FUSE IN THE CIRCUIT BETWEEN THE TOW VEHICLE BATTERY AND AN ELECTRIC OR ELECTRONIC BRAKE CONTROLLER. A BLOWN FUSE WILL CAUSE THE CONTROLLER TO CEASE FUNCTIONING BOTH AUTOMATICALLY AND MANUALLY CAUSING LOSS OF TRAILER BRAKING WITH NO ADVANCE WARNING.



3. **Connector Plug:** The multi-pin cord connector at the front of the trailer transfers electrical power from the tow vehicle battery to the trailer brakes, exterior lighting system, and battery.

4. **Breakaway Switch:** The breakaway switch is located on the trailer tongue. It has a steel cable (lanyard) fastened to it which will reach to the frame of the tow vehicle. This device is one of the most vital components on your trailer's braking system. It automatically applies the trailer brakes if the tow vehicle and trailer become uncoupled while in motion. The breakaway switch operates when a pull pin linked by the cable to the tow vehicle is separated from the switch. When the switch closes, power for brake application is transferred to the onboard trailer battery. The steel lanyard must be anchored to the tow vehicle when the trailer is hitched up. Secure this cable loop to the permanent frame of the tow vehicle or a part of the hitch that is not removable.

WARNING: DO NOT FASTEN THE BREAKAWAY SWITCH LANYARD TO THE HITCH BALL OR ANY OTHER REMOVABLE PART OF THE HITCH.

Remove the pull pin every three months and lubricate it with light oil. Before reinserting the pin, spray the inside of the switch with an electrical contact cleaner to prevent corrosion. Test the breakaway switch operation before each trip as follows:

- a. Hitch the trailer to the tow vehicle.
- b. Pull out the breakaway switch actuating pin. Never leave the actuating pin out for more than a few seconds as damage can result to wiring or the brakes. When the pin is out the full power of your battery(s) is channeled to the brakes, which could result in possible damage to the brakes or the wiring when the actuating pin is left out for an extended period of time.
- c. Test brakes by attempting to drive away. The breakaway switch is functioning properly if the trailer brakes are activated. Complete this test quickly.
- d. If the brakes are not activated, check that the trailer battery is connected and fully charged and the trailer brakes are properly adjusted.
- e. Obtain service repair if the trailer brakes do not operate after making these checks.

- f. Reinsert the breakaway switch actuating pin before towing the trailer.

WARNING: DO NOT TOW A TRAILER WITH A MALFUNCTIONING BREAKAWAY SWITCH.

WARNING: DO NOT LEAVE THE PULL PIN OUT OF THE BREAKAWAY SWITCH FOR MORE THAN A FEW SECONDS (30 TO 60 SECONDS) OR THE BATTERY WILL BE DRAINED. DO NOT USE THE BREAKAWAY SWITCH FOR A PARKING BRAKE.

5. **Grounding:** A poor ground circuit from the brakes to the tow vehicle battery can be as detrimental to efficient braking as a poor primary circuit from the battery to the brakes.

BRAKING TIPS:

- Before moving your trailer, inspect all external braking system components. Inspect all wiring connections. Test the breakaway switch as outlined above.
- Never use the trailer brakes alone for extended periods.
- Never use the tow vehicle brakes alone.
- Always use the automatic brake controller. This synchronized braking system enables you to drive in the manner recommended by experts.

TOWING SPEED

Reasonable vehicle speed is probably the greatest factor in safe, pleasant towing. With experience you will develop the special driving skills needed for safe trailer towing.

WARNING: TOW AT MODERATE SPEEDS ALLOWING FOR ADVERSE HIGHWAY AND WIND CONDITIONS. INCREASED SPEED REDUCES TRAILER TOWING STABILITY, HANDLING AND STOPPING ABILITY.

WARNING: DO NOT USE A CRUISE CONTROL OR AUTOMATIC SPEED REGULATING DEVICE WHEN TOWING A TRAILER.

WARNING: DO NOT ATTEMPT TO STOP TRAILER SWAYING BY QUICK STEERING CHANGES OR BY FORCEFULLY APPLYING THE TOW VEHICLE BRAKES. IT IS BEST TO USE THE MANUAL LEVER LOCATED ON YOUR BRAKE CONTROL.

Please review the Safe Driving Tips outlined in General Information and Helpful Hints.

LIFE WITH YOUR NEW TRAILER

ENTRY STEP: Folding or sliding entry steps are located under each entry door. Some models may have double or triple steps.

To extend the double or triple step: Pull complete step assembly out; let it down completely. Unfold bottom step(s) from over top step and lower completely. Reverse to retract.

ENTRY ASSIST HANDLE: An entry assist handle is located outside each entry door. Many models have an additional assist handle inside the entry door.

ENTRY DOORS, SCREENS, AND LOCKS: Entry door locks and deadbolts are keyed alike. If your unit has two entry doors, there will be a separate set of keys for each door. If your keys are numbered, be sure to record all key numbers and keep them in a safe place. When using the screen door, you can secure the main door against the side of the trailer with the exterior door latch.

NOTE: It is always a good idea to lock the entry door deadbolt(s) before traveling. This will reduce the possibility of the door(s) opening on the road.

WINDOWS: Windows in your trailer are either slider or torque pane type. Slider windows may be opened by pulling out the latch knob--when the slider window is closed the latch will automatically lock into place. Torque windows may be opened and adjusted by turning the knob or crank located at the bottom corner of the window.

EMERGENCY EXIT WINDOW: The emergency exit window provides an escape route in case the trailer must be evacuated under emergency conditions. To operate the window, pull the red handle(s) and push the window out. **DO NOT BLOCK EMERGENCY EXIT WINDOW.**

EXTERIOR COMPARTMENTS: Exterior storage compartments in the trailer maximize available space and should accommodate most of your storage needs. All of the storage compartments can be locked. **THE LP GAS COMPARTMENT IS REQUIRED BY SAFETY REGULATIONS TO BE UNLOCKED AT ALL TIMES.** All compartments have been designed to remain secure while the vehicle is in motion.

When storing equipment and supplies:

1. Always keep tools and equipment stored in areas where they will not shift while traveling.
2. Exterior storage compartments may not be watertight in all weather and road conditions. Any articles which could be damaged by water or dirt should be carried inside the trailer.

DINETTE CONVERSION: To convert the booth dinette into a bed:

1. Remove cushions.
2. Lift table, reach underneath, unlatch and fold the leg up under the table top--or remove the table leg(s) if necessary and store between the seats.
3. Raise front portion of table several inches to disengage inserts from the wall supports.
4. Lower table top to the dinette frame to complete bed base.
5. Slide seat and back cushion into place over bed base.

OPERATING THE SLIDE OUT ROOM (ONLY FOR MODELS HAVING A SLIDE OUT ROOM)

EXTENDING THE SLIDE OUT ROOM: Before operating your slide out room the trailer must be level and stable.

1. Level each side by using blocks under the tires if necessary and adjusting the front landing gear on 5th-wheels or front jack on travel trailers.
2. Level the trailer from front to back using the front landing gear or front jack.
3. Lower the stabilizer jacks provided with all slide out room equipped units. These are designed to stabilize the unit, but not to support its full weight.
4. If the trailer is not leveled, it could damage the slide out room, seals and/or slide out mechanism.
5. **REMOVE TRAVEL LOCKS:** After the unit has been leveled and stabilized you must remove the two (2) travel locks before operating the slide out room. There is one (1) aluminum rubber tipped rod located on each side of the slide out room. Small slides may only have one rod.
6. Check around the room for any obstructions such as open cabinet doors or furniture.
7. You are now ready to extend the slide out room. Locate the slide out switch. Hold the switch in the "OUT" position until the room comes to a stop. Release the switch.

NOTE: YOUR BATTERIES NEED TO BE ADEQUATELY CHARGED AND YOU NEED TO BE CONNECTED TO YOUR TOW VEHICLE OR 120-VOLT POWER IF IT IS AVAILABLE TO ENSURE PROPER FUNCTION OF THE SLIDE OUT MECHANISM.

8. Never attempt to move your trailer with the slide out room extended. This will cause damage to the room and/or the trailer.

CLOSING THE SLIDE OUT ROOM:

1. Look for any obstructions around the slide out room both interior and exterior.
2. Locate the slide out switch and hold in the "IN" position until the room is in and comes to a

- stop. Release the switch.
3. Replace the travel locks (aluminum rods) to their original position--one on each side of the slide out room.
 4. Raise the stabilizer jacks.
 5. Now the slide out room is ready for travel.

IMPORTANT: BE SURE TO REFER TO MANUFACTURER'S INSTRUCTIONS FOR THE SPECIFIC SLIDE MECHANISM ON YOUR UNIT. i.e. BEDROOM MECHANISM IS NOT THE SAME AS THE LIVING ROOM/DINING ROOM SLIDE MECHANISM.

NOTE: REFER TO MANUFACTURER'S INSTRUCTIONS FOR MANUAL OPERATION OF SLIDE MECHANISM IN CASE OF ELECTRICAL FAILURE.

FRESH WATER SYSTEM

Fresh water is supplied to the trailer by two alternate sources.

1. The external hookup (city or park water).
2. Self-contained water (on board storage tank).

EXTERNAL HOOKUP (City or Park Connection): To use the external water system connect the water hose from the city or campground source to the hose connector on the side of your unit. Be sure to run the water for a few seconds to clear the hose before connecting to the unit. A check valve at the water pump prevents city water from being fed back through the pump and into the water tank. Another check valve prevents water from being pumped out through the city water connection when the self-contained water system is being used in the unit. The water heater is equipped with a safety-relief valve which will open if a surge of pressure should occur. The water system has been tested for leaks at the factory at 90-100 PSI.

IMPORTANT: EXCESSIVE WATER PRESSURE. Some city or campground water systems may operate at pressures that can damage the water system in your trailer or cause water pump failure. If pressure at your site is over 70 PSI, you must use a pressure regulator. The recommended pressure range is from 35 PSI to 45 PSI. Your RV supply dealer can advise you on the best choice regarding water pressure regulators.

IMPORTANT: The 12-volt DC water pump switch should be in the "OFF" position when the trailer is connected to a city or campground source.

SELF-CONTAINED WATER SYSTEM: The fill spout for the onboard fresh water storage tank is located on the outside of the trailer. The electric 12-volt DC pump supplies the pressure for the self-contained water system. You can check the approximate water level by pressing the "water" rocker switch on the monitor panel. Erroneous readings could be caused by water with low mineral content.

FRESH WATER FILL INSTRUCTIONS: (See Diagram Page 14A) The access door for the fresh water fill spout is located on the side of the trailer. The fill spout is connected by a hose to the onboard fresh water storage tank. There is a small vent hole adjacent to the filler spout. This vent relieves air from the onboard fresh water tank.

1. Fill slowly and be sure that the hose you use to fill the on-board water storage tank is smaller than the water fill opening to allow excess water and air to escape as tank fills. The higher the pressure of water you force into your water tank the greater the likelihood of damage to your trailer. When you force water into a water tank you can actually balloon a 40-gallon tank to accept 60 gallons of water swelling the tank to a size too large to be contained in the area that houses the tank. This pressure can actually tear apart the structure of the floor on your trailer.
2. Do not leave the trailer unattended while filling.
3. Do not wedge the water hose into the fill spout.
4. "Full condition" indication is water back flushing by the water hose and out of the air vent adjacent to the fill spout.
5. Discontinue filling immediately on observation of "full" signal.

CAUTION: Improper filling can cause hydraulic force which can damage your trailer floor sections. You must leave space around fill hose (AN OVERSIZED HOSE WILL NOT ALLOW THE SPACE REQUIRED TO PREVENT PRESSURE BUILD UP). The vent can only release a fraction of the pressure created when filling tank. **CAUTION:** Always fill your onboard water tank in such a way as to allow excess water to escape through the water fill and vent. BEFORE FILLING YOUR TRAILER FOR THE FIRST TIME YOU NEED TO READ AND UNDERSTAND THE WARNINGS SET OUT IN DIAGRAM. (Page 14A)

WARNING: ONLY USE POTABLE WATER IN THE WATER TANK. SANITIZE, FLUSH AND DRAIN THE WATER TANK BEFORE USING.

SANITIZING THE FRESH WATER SYSTEM: The following procedures are recommended to assure complete sanitation of your potable water system. This applies to a new system, one that may have become contaminated or one that has not been used for a period of time.

1. Prepare a solution of 1/4 cup household liquid chlorine bleach (5% sodium hypochlorite) to one gallon of water. This solution will treat 15 gallons of fresh water. You will need to increase solution proportions to the tank capacity of you trailer.
2. Close drain valves and faucets, pour chlorine solution into the fresh water tank filler spout. Fill tank completely with fresh water.
3. Turn water pump switch "ON." **Be sure you have 12-volt DC power.** Open all faucets individually until water flows steadily and you detect a distinct odor of chlorine--then turn faucets off. Do not forget the hot water taps. This will purge any air from the lines.
4. Top off water tank with fresh water and wait 3 to 4 hours.
5. Drain the entire system by opening all fresh water tank valves, faucets and plumbing line drain valves.
6. Flush the system with drinking quality water, close drain valves and refill the water tank with fresh water and repeat the steps set out in step 3 (omitting the chlorine solution). Let the fresh water flow through the system for several minutes to flush out the chlorine

solution.

7. After you finish flushing the fresh water system drain the entire system by repeating the steps set out in step 5. You can now close the tank valve, faucets, and drain valves and fill the tank with fresh drinking quality water. The system is ready to use.

To remove any excessive chlorine taste or odor which might remain in the potable water system, prepare a solution of one quart vinegar to five gallons water. Allow this solution to agitate in tank through vehicle motion. Drain tank and flush again with potable water.

ELECTRIC 12-VOLT DC WATER PUMP: The onboard fresh water system is pressurized by a self-priming, 12-volt DC pump. The water pump operates automatically when the water pump power switch is "ON" and a faucet or valve is opened. Turn the water pump "ON" to pressurize the system. When a faucet is opened after the initial filling of the tank, the water may sputter for a few seconds. This is normal and is not cause for concern. In the "ON" position the water pump delivers water to the water heater and faucets and maintains a positive pressure through the system. **IMPORTANT:** It is recommended to turn the water pump switch "OFF" whenever you are away from the trailer. **IMPORTANT:** Do not run the water pump without water in the system.

THE MONITOR PANEL: The monitor panel allows you to check the approximate liquid levels in the fresh water and holding tanks, and to monitor battery charge conditions.

1. Press "WATER" or "BLACK TANK" or "GRAY TANK" rocker switches.
2. Erroneous indications can be caused by:
 - a. Water with low mineral content.
 - b. Material trapped on the sides of the holding tanks may give a full reading when the tank is actually empty. Use of a spray to wash out the tank following dumping should help prevent this condition.

WASTE WATER SYSTEM

The waste water system in your trailer is made up of sinks, tub, shower, toilet, plumbing drain, vent lines, "gray water" holding tank and a "black water" holding tank. The holding tanks make the system completely self-contained and allow you to dispose of waste water at your convenience. A flexible sewer hose is required to connect the holding tank outlet to the inlet of an approved waste water dump station or sewer system. The drain plumbing is very similar to that used in your home. The system is trapped and vented to prevent waste gases from backing up into the trailer. The drain plumbing is durable and resistant to most chemicals. All drain plumbing except the toilet connection terminates in the gray water holding tank. The toilet is mounted on the black water tank and flushes directly into it.

The holding tanks terminate in a valve arrangement that permits dumping each tank separately. The valves are called "knife valves." A blade closes the opening in the sewer drain pipes. The blade is connected to a T-handle that is pulled to release the contents of the tank(s). During self-containment use, the sewer line is securely capped to prevent leakage of waste material onto the ground or pavement. **DO NOT PULL THE HOLDING TANK KNIFE VALVE OPEN WHEN THE PROTECTIVE CAP IS INSTALLED ON THE PIPE.** Always ensure that the tank is evacuated into an acceptable sewer inlet or dump station.

WARNING: HOLDING TANKS ARE ENCLOSED SEWER SYSTEMS AND AS SUCH

MUST BE DRAINED INTO AN APPROVED DUMP STATION. BOTH TOILET AND GRAY WATER HOLDING TANKS MUST BE DRAINED AND THOROUGHLY RINSED REGULARLY TO PREVENT ACCUMULATION OF TOXIC MATERIALS.

It is recommended that you only dump the holding tanks when they are at least 3/4 full. If necessary, fill the tanks with water to 3/4 full. This provides sufficient water to ensure complete flushing of waste material into the sewer line.

DUMPING THE HOLDING TANKS:

- a. First make sure the dump valve is closed.
- b. Remove the sewer drain cap and attach the sewer adapter and drain hose to the dump valve drain outlet. Place the other end of the drain hose into the sewer or dump station inlet. Push the hose firmly far enough into the opening to be secure. In some cases adapters may be necessary between the line and the inlet.
- c. Arrange the sewer hose so it slopes evenly and is supported to maintain the slope.
- d. Dump the black water holding tank first. Grasp the handle of the black water knife valve (the large one) firmly and slide the valve open with a quick, steady pull. **IMPORTANT:** Always open the dump valve with a quick jerk to give the desired flushing effect.
- e. Allow enough time for the tank to drain completely. Rinse and flush the tank and drain hose through the toilet with a bucket of water or a hose. When the tank flow stops, push the handle in to close the valve. Run enough water into the tank to cover the bottom. This will aid the break up of solid wastes.
- f. When using a sewer hook-up system in a park, it is recommended to keep the dump valve closed on the black water tank until it is full. This will help prevent accumulation of waste material that could clog the system.
- g. To dump the gray water tank, repeat the steps above using the small knife valve. The gray water knife valve may be left open in a semipermanent hookup.

IMPORTANT: Do not dump both tanks at the same time. Also, it is recommended that you add several gallons of water to each holding tank and dump a second time in order to thoroughly rinse tanks and drain hose.

If solids become lodged in the tank, add water to the tank and drive the unit a few miles. The vibration and motion should dislodge the solids. If an obstruction should remain, contact your dealer or trailer supply store for a suitable cleaning compound.

**WARNING: SEWER DRAIN CAP MUST ALWAYS BE SECURELY
IN PLACE WHILE THE VEHICLE IS IN MOTION.**

PLEASE PRACTICE GOOD HOUSEKEEPING WHEN DRAINING WASTES AT A CAMPSITE OR DISPOSAL STATION. LEAVE THE SITE IN GOOD ORDER.

HOLDING TANK CARE AND MAINTENANCE:

1. Keep the black water tank knife valve closed. Fill tank to at least 3/4 full before dumping. Be sure to cover the tank bottom with water after dumping.
2. Use only toilet tissue formulated for use in septic tank or RV sanitation systems.
3. Keep both knife valves closed and the drain cap tightly in place when using the system on the road.
4. Do not put facial tissue paper, ethylene glycol-based or other automotive antifreeze, sanitary napkin, or household toilet cleaners in the holding tanks.
5. Sometimes the holding tank valve will get clogged. In this case, a hand operated auger may be necessary. Be ready to close the valve quickly once the clog is cleared. If the seal gets damaged, it is easily replaced.

WARNING: FULL HOLDING TANKS CAN RADICALLY CHANGE THE TOWABILITY OF YOUR UNIT. DO NOT TRAVEL WITH FULL HOLDING TANKS.

TOILET: The marine toilet operates in a manner similar to a household type toilet except it is designed to flush using a minimum amount of water. Read the manufacturer's instructions for operating procedures on the specific type of toilet installed in the trailer.

ELECTRICAL SYSTEMS

CHASSIS ELECTRICAL SYSTEM: The vehicle electrical system includes the trailer battery, charging system, brake system, taillights, turn signals, and other vehicle lights and accessories.

The power center is the nerve center of the 12-volt DC--as well as the 120-volt AC-- system. Fuses for the 12-volt DC circuits are located at the power center panel. These fuses are automotive type and should always be replaced with the same type and amperage rating.

WARNING: DO NOT INSTALL 12-VOLT FUSES WITH AMPERAGE RATINGS GREATER THAN THAT SPECIFIED ON THE FUSE BOX LABEL.

Battery condition can be checked on the Monitor Panel. To check the battery charge:

1. Unplug the 120-volt power cord to turn the power converter off.
2. Press "BATTERY" rocker switch on the panel.
3. Turn on a light or any 12-volt appliance. The battery must be checked with a load.
4. Read battery condition on the meter. Red is poor, yellow is fair, and green is good.

WARNING: DISCONNECT THE 120-VOLT ELECTRIC CORD AND BOTH CABLES FROM THE TRAILER BATTERY BEFORE WORKING ON EITHER ELECTRICAL SYSTEM.

BATTERY CHARGING: Normally the battery will be kept charged by either the tow vehicle charging system while on the road or by the AC/DC power converter when plugged into AC service.

IMPORTANT NOTE: Always leave home with a full charge on your battery(s). A slow trickle charge is best for long battery life. It requires at least 52 hours to fully charge an RV battery on a trickle charger. Once your battery(s) is fully charged, your power converter will maintain the battery(s) to full peak while your unit is plugged into 120-volt shore power and your tow vehicle charging system will keep the battery(s) at full peak while traveling.

Do not smoke near batteries being charged or which have been recently charged. Please note that batteries are being charged while you drive and while you are connected to 120-volt AC power through the power center/charger circuit.

Check and adjust the electrolyte level before charging. Fill each cell to the indicator with distilled water.

120-VOLT AC SYSTEM: This system provides grounded electrical service for appliances such as the air conditioner, TV, microwave oven, etc. The 120-volt system also provides a power source for the power center. Do not use a two-conductor extension cord or any cord or cable that does not assure appropriate and adequate ground continuity.

THE POWER CENTER: The power center will supply 12-volt requirements when your trailer is operating on 120 AC volts. Thus, you will not have to worry about running down the battery. When you are plugged into 120-volt AC service, the power center automatically switches the load from the battery to the power center. The onboard battery will gradually be brought up to a full charge and maintained by the battery charger as long as 120-volt power is available.

NOTE: The 12-volt battery is not supplied with the trailer by the trailer manufacturer.

GROUND FAULT INTERRUPTER: Kitchen, bathroom and patio 120-volt electrical outlets are protected by a Ground Fault Interrupter (GFI). This device is provided in compliance with ANSI A119.2/NFPA 501C requirements and is intended to protect you against the hazards of line to ground electric faults and electrical leakage shocks possible when using electrical appliances in the kitchen, or damp areas inside or outside of the unit. Whenever you plug your 120-volt system into shore power, it is recommended that you verify that the adapter and power source are wired in proper sequence. Occasionally we have found that some home or garage wiring installations have been done improperly. Even though your trailer may appear to operate properly, there is danger of electrical shock—especially in wet areas—if power source wiring has been incorrectly installed in the home, garage or other facility. If the shore power has been improperly wired, the built in safety devices in your trailer may not function correctly. A simple continuity checker (wiggie) will verify wiring integrity. If you suspect that an external extension cord or adaptor may not have been

supplied by a properly licensed electrician, be sure to check the power source before use to avoid the danger of an electrical shock.

LPG (LIQUEFIED PETROLEUM GAS) SYSTEM

The furnace, range, oven, water heater, refrigerator and optional generator all operate on LPG.
(SEE PAGE 34 SAFETY REGULATIONS REGARDING LP GAS SYSTEMS AND LP GAS APPLIANCES)

CAUTION

LPG is a colorless, highly flammable gas which has been treated chemically to have a pungent odor smelling like garlic. This helps the user to detect the presence of the gas. LPG is heavier than air; therefore, it displaces the air in low pockets and could cause suffocation or explosion if not detected.

The two most common types of LPG are butane and propane. Both types work equally well in the LPG system of your recreational vehicle. Butane can only be used down to a temperature of 32° F above zero. Propane can be used down to a temperature of 40° F below zero.

Your LP Gas dealer will supply you with the fuel mixture best suited for your area.

LPG TANKS: The LP Gas tanks are tested high pressure cylinders. LPG is stored in these tanks under high pressure which maintains the LPG in a liquid/vapor condition. The 10% valve or pressure relief valve has been located on the top of the tank so that it will always be in the vapor area. If the tank is over filled or if the temperature of the tank is raised, this valve will release. This valve should be **HAND TIGHTENED ONLY**.

LP GAS PRESSURE REGULATOR: The two-stage LPG pressure regulator reduces the high pressure vaporized LPG down to a pressure of a 13" water column. At this pressure LPG is piped to and used by the various LP Gas fired appliances. Do not make any adjustments to the LPG pressure regulator. Adjustments should only be made by an authorized LP Gas service technician.

IMPORTANT: LP Gas pressure regulators must always be installed with the diaphragm vent facing downward. Regulators that are not housed in a compartment have been equipped with a protective cover. It is very important that the regulator vent faces downward and that the cover is kept in place to minimize vent blockage which could result in excessive gas pressure causing fire or an explosion. This opening is located at the bottom of the spring case and should be checked periodically to see that it has not become plugged by insects, mud, ice or other debris.

VENTING: All LP Gas fired appliances use oxygen from the air. It is necessary to provide proper ventilation when occupying your unit to avoid the danger of asphyxiation. For best ventilation open a window and roof vent.

FILLING LP GAS TANKS:

1. Close the tank valve on the empty tank.
2. Loosen and remove spud nut. **IMPORTANT: THIS IS LEFT HAND THREAD.**
3. Loosen the clamp holding the tank to the unit.
4. Remove tank from unit.
5. Have the tank filled by an authorized LP Gas dealer.
6. Observe labels and tags.

The WARNING LABEL located near the LPG container reads:

**DO NOT FILL CONTAINER(S)
TO MORE THAN 80% OF CAPACITY**

Overfilling the LPG container can result in uncontrolled gas flow which could result in fire or an explosion. A properly filled container will contain approximately 80% of it's volume as liquid LPG.

LPG TANK INSTALLATION:

1. Position filled tank.
2. Engage the spud-nut service connector to main tank valve. **IMPORTANT: THIS IS LEFT HAND THREAD.**
3. Tighten nut snugly with wrench. **DO NOT USE PLIERS.** **IMPORTANT:** This is a mechanical brass seal, it does not require pipe sealer.
4. Secure tank.
5. Check all tank and line connections to be sure they are tight.
6. Test for leaks using a soapy water solution and watch for enlarging soap bubbles.
7. Observe labels and tags.

START-UP and OPERATION OF LP GAS APPLIANCES:

1. Check to be sure that all appliance gas supply valves are in the off position.
2. Read the manufacturer's start-up and shut-off instruction manuals for each respective appliance.
3. You are now ready to light your LPG appliances. **IMPORTANT:** It may be necessary to purge air from the LPG supply lines on initial lighting of the LPG appliance. To purge the air from the supply line, open a pilot or burner valve. Hold a flame near the burner, after several seconds the air will escape and the gas will ignite and burn.

LPG SAFETY PRECAUTIONS:

- Inspect the entire LPG system for possible leaks or damaged parts before each trip.
- When testing for leaks use soapy water.
- **WARNING:** Never check for LP Gas leaks with an open flame.
- Never lock the LPG compartments. **THE LP GAS COMPARTMENT IS REQUIRED BY SAFETY REGULATIONS TO BE UNLOCKED AT ALL TIMES.** The tank service valve should always be accessible in case of an emergency.
- **WARNING:** Do not place or store an LP Gas container inside the vehicle. LPG containers are equipped with safety devices which relieve excessive pressure by discharging gas into the atmosphere.
- Only have the LPG tank filled by an authorized LP Gas dealer.
- Always make certain that the tank is secured in place.
- Always extinguish all LPG appliance pilot lights before refueling the gasoline tank on your vehicle.
- Never use an upright tank in a laydown position or a laydown tank in an upright position.

- Use caution when drilling holes or fastening objects to the walls or floor of your trailer. Gas lines could be damaged and present an extreme safety hazard.
- **WARNING:** Never use natural gas in you LPG system.

USING LP GAS SYSTEM AT LOW TEMPERATURES: Your gas system will function at low temperatures provided the system components are kept at a temperature above the vapor point of the LP gas.

NOTE: If temperature drops lower than 40°F below zero, propane will not vaporize.

LP gas systems can and do freeze up in very cold weather. It is a common misconception that the regulator or the gas itself freezes. Actually, it is moisture or water vapor that gets trapped in the system or is absorbed by the gas that freezes and causes the problem. This ice can build up and partially or totally block gas supply. There are a number of things you can do to prevent this freeze up:

1. Be sure the gas tank is totally moisture-free before it is filled.
2. Be sure the tank is not overfilled. This is also a safety consideration.
3. Keep the valves on empty tanks tightly closed.
4. Have the gas tanks purged by the LP gas service dealer if freeze up occurs.

APPLIANCES and EQUIPMENT

Most LPG appliances have lighting procedures on a plate that is permanently attached to the appliance.

For detailed operating information please refer to the specific manual supplied by the respective manufacturer which has been included in your owner's packet. All appliances are warranted by the respective manufacturer.

LP GAS (LPG) LEAK DETECTOR: The LPG leak detector is located near the floor in the galley area. The LPG leak detector contains an alarm that will sound alerting you to the presence of low levels of potentially dangerous LP gas that may have been released due to a range top or oven burner flame loss, gas pipe leak, or an incorrectly adjusted appliance burner.

IMPORTANT: THIS DEVICE DETECTS THE PRESENCE OF LP GAS—IT DOES NOT DISCONNECT THE GAS SUPPLY.

Read the owner's manual supplied by the manufacturer for details on testing and maintenance of the LPG leak detector. This detector is an important safety device. **IMPORTANT: TEST THE LPG LEAK DETECTOR BEFORE EACH TRIP TO INSURE THAT IT IS WORKING PROPERLY.**

FURNACE: The furnace operates on LP Gas fuel. Before using the furnace read the owner's manual supplied by the manufacturer of the furnace for a complete understanding of how to safely light and use the furnace as intended by the manufacturer. Be sure all heat registers are open and unobstructed to prevent the furnace from cycling due to excessive heat build up in chamber.

WATER HEATER: The water heater operates on LP Gas fuel. Before using the water heater read the owner's manual supplied by the manufacturer of the water heater for a complete understanding of how to safely light and use the water heater as intended by the manufacturer. Controls for the

water heater are located behind the access panel on the outside of your recreational vehicle. If your trailer is equipped with a Direct Spark Ignition (DSI) system, please read owner's manual supplied by the manufacturer for proper lighting procedure. If you have the optional Direct Spark Ignition (DSI) system with LP Gas fuel and 120-volt element, please read the owner's manual supplied by the manufacturer for the optional DSI gas/electric water heater for proper lighting procedure.

IMPORTANT: Before turning on the water heater make sure that the water heater is filled with water. Be sure that the water heater by-pass valve is not in the by-pass position (see diagram on Page 25A for correct direction of by-pass valve).

GENERATOR (optional equipment): The generator operates on LP Gas. For detailed operating and maintenance instructions refer to the owner's manual supplied by the manufacturer.

IMPORTANT: Always check to make sure that the generator has adequate ventilation and that vents and/or exhaust have not been blocked by snow or other objects that may damage exhaust pipe and restrict flow of exhaust away from vehicle. **AVOID THE DANGER OF CARBON MONOXIDE (CO) POISONING** read the owner's manual for a complete understanding of how to safely use the generator. It is never recommended to run the generator while occupants are sleeping.

IMPORTANT: Always be sure that your CO detector is operating.

IMPORTANT: A trailer that has been built generator ready requires that the exterior compartment door be a vented door. If you install a generator in a generator ready unit, you must insure that the exterior compartment door is vented. **AVOID THE DANGER OF CARBON MONOXIDE (CO) POISONING. AN ON-BOARD GENERATOR MUST NOT BE OPERATED WITHOUT ADEQUATE VENTILATION.**

WARNING: A customer not planning to install a generator in a generator ready unit may have installed a solid door on the generator compartment. **MAKE SURE THAT THE GENERATOR COMPARTMENT HAS A VENTED DOOR** before using or installing an on-board generator.

RANGE TOP BURNER AND OVEN: The top burners of the range and oven operate on LP Gas.

WARNING: It is not safe to use cooking appliances for comfort heating.

COOKING APPLIANCES NEED FRESH AIR FOR SAFE OPERATION.

BEFORE OPERATION:

- 1. OPEN OVERHEAD VENT OR TURN ON EXHAUST FAN, AND**
- 2. OPEN WINDOW**

This warning label has been placed in the cooking area to remind you to provide an adequate supply of fresh air for combustion. Unlike homes, the amount of oxygen supply is limited due to the size of the recreational vehicle. To avoid the danger of asphyxiation provide for proper ventilation when using cooking appliances. **IMPORTANT:** The danger of asphyxiation is greater when the appliance is used for long periods of time—**DO NOT USE COOKING APPLIANCES FOR COMFORT HEATING.**

REFRIGERATOR: The refrigerator may be operated from either LP gas or 120-volt electric power. Consult the operating instructions furnished in your Owner's Information Package.

NOTE: If your refrigerator is equipped with a "humidity" switch, set it to "OFF" if you will not be using

the trailer for 10 days or longer. This will help reduce battery drainage.

SMOKE DETECTOR: A battery-powered smoke detector complying with ANSI A119.2/NFPA 501C is mounted on the ceiling or wall in the living/cooking area of your trailer. Please read the smoke detector Owner's Manual for details on testing and caring for this important safety device.

FIRE EXTINGUISHER: The fire extinguisher is mounted on the wall near the entry door of your trailer. Please read the owner's manual supplied by the manufacturer for details on testing and maintenance on this important safety device.

CARBON MONOXIDE (CO) DETECTOR (when trailer has on-board generator): The CO detector is usually mounted on the ceiling above the bed in your trailer. **IMPORTANT:** This detector is designed to provide warning when low levels of carbon monoxide are detected in the surrounding air. **CARBON MONOXIDE GAS IS POISON.** Utmost care should be taken to avoid the danger of CO poisoning.

IT IS VERY IMPORTANT TO read the owner's manual supplied by the manufacturer of the CO detector for details on testing and maintenance on this important safety device. The unit should be tested to insure that it is operating properly before each trip and frequently during the time you are staying in the trailer.

POWER RANGE EXHAUST HOOD: The power range exhaust hood is located above the range burners and operates on 12-volt power. For detailed operating information and maintenance please refer to the owner's manual supplied by the manufacturer.

MICROWAVE OVEN (option): The microwave oven operates on 120-volt AC power accessed through 120-volt AC power from either a public utility or a generator (optional equipment). For detailed operating information and maintenance please refer to the owner's manual supplied by the manufacturer.

ROOF MOUNTED AIR CONDITIONER (option): The air conditioner operates on 120-volt AC power accessed through 120-Volt AC power from either a public utility or a generator (optional equipment). Be sure to turn the circuit breaker "ON." Before using the air conditioner read the owner's manual supplied by the manufacturer of the air conditioner for a complete understanding of operation and maintenance.

FANTASTIC VENT (option): The fantastic vent operates on 12-volt power. For detailed operating information and maintenance please refer to the owner's manual supplied by the manufacturer.

A/M F/M STEREO TAPE OR CD PLAYER (option): For detailed operating information and maintenance please refer to the owner's manual supplied by the manufacturer.

TV ANTENNA (option): For detailed operating information and maintenance please refer to the owner's manual supplied by the manufacturer.

OTHER ESSENTIAL INFORMATION

WINTER PROTECTION

WINTER PROTECTION WHILE TRAILER IS IN USE: When using the trailer in cold weather be sure there is adequate circulation of warm air from the furnace around all water pipes. Leaving the bath door and cabinet doors open will help to avoid freezing pipes. Keep the ceiling vent slightly open.

You can reduce or eliminate interior moisture condensation during cold weather by partially opening one or more roof vents and windows to provide controlled circulation of outside air into the interior of the trailer.

You can install storm windows to help reduce or eliminate condensation on window glass.

WARNING: DO NOT COVER THE EMERGENCY EXIT WINDOW.

WARNING: DO NOT HEAT THE TRAILER INTERIOR WITH THE RANGE OR OVEN.

PREPARING FOR LONG-TERM STORAGE:

DRAINING THE WATER SYSTEM: Protecting the plumbing systems in the trailer is the most important aspect of long-term winter storage.

1. Drain the fresh water tank by opening the water tank drain valve. Leave valve open.
2. Open the hot and cold water line drain valves.
3. Drain the water heater by opening the drain valve (remove the plug) at the bottom of the heater and open the safety valve by lifting up the lever on the relief valve. Open the hot water faucets.
4. Open all cold water faucets and activate the flush mechanism on the toilet. When each faucet has been opened, drained, and closed, close the water line drain valves and fresh water tank drain valve.
5. Drain the shower head by opening the valve. Let all water drain out of the tub spout. Leave the valve open.
6. Apply graphite lubricant to the knife valve actuator rod.

WINTERIZING WITH NON-TOXIC ANTIFREEZE: There are non-toxic antifreeze type additives which have been specifically designed for use in recreational vehicle fresh water and waste systems. This non-toxic antifreeze when rinsed out of the fresh water system should leave no residue or bad taste.

WARNING: DO NOT USE ETHYLENE GLYCOL BASE (AUTOMOTIVE TYPE) ANTIFREEZE IN THE FRESH WATER SYSTEM.

CAUTION: DRAINING THE WATER SYSTEM ALONE MAY NOT PROVIDE ADEQUATE COLD WEATHER PROTECTION. IF THE TRAILER IS TO BE UNHEATED DURING FREEZING

TEMPERATURES, CONSULT YOUR DEALER FOR THE BEST WINTERIZING PROCEDURE FOR YOUR CLIMATE. YOUR DEALER CAN WINTERIZE YOUR TRAILER FOR YOU OR CAN SUPPLY YOU WITH ONE OF THE SPECIAL ANTIFREEZES WHICH ARE SAFE AND APPROVED FOR USE IN RV WATER SYSTEMS. FOLLOW THE INSTRUCTIONS FURNISHED WITH THE ANTIFREEZE.

SEMI-AUTOMATIC WINTERIZATION SYSTEM: (DIAGRAM ON PAGE 25A) Winterizing the trailer for storage during freezing temperatures can be accomplished easily with the semi-automatic winterization system. See your dealer or trailer supply store for the amount of non-toxic antifreeze to use in your trailer.

1. Drain all tanks: fresh water, black water and gray water. Drain hot water heater.
2. The water system in the trailer is equipped with two each two-position valves. The first is located inside your trailer in the back of your water heater, turn it to the by-pass position as indicated in the diagram. (Page 25A)
3. Next locate valve between your water tank and water pump. Turn the valve to the up position to draw potable antifreeze into the system as indicated in the diagram. (Page 25A)
4. Place open end of the hose into a bottle of approved non-toxic RV antifreeze.
5. Turn the water pump master switch ON.
6. Open each water faucet. Run the water pump and let about one cup of non-toxic antifreeze solution flow continuously through each faucet to circulate the non-toxic antifreeze throughout the entire fresh water and gray water waste systems and traps. Close each water faucet. Flush toilet until you see the colored non-toxic antifreeze draining into the black water tank.
7. Turn the water pump OFF. Open water faucet to relieve pressure--then close.

Winterization of the fresh water system is complete.

IMPORTANT: ALL FRESH WATER LINES MUST BE FLUSHED WITH FRESH WATER TO CLEAR THE FRESH WATER SYSTEM OF ANY ANTIFREEZE PRIOR TO USING FRESH WATER SYSTEM.

OUTDOOR WINTER STORAGE INSTRUCTIONS:

EXTERIOR: Outdoor winter storage requires certain precautions to prevent condensation of excessive moisture which can cause musty odors and mold. If you decide that it is important to protect your vehicle in areas of heavy precipitation through the use of a vinyl type tarp, do not cover the unit in such a way that no air can circulate. If your unit is covered, it is important to provide some air circulation within the unit by cracking a roof vent and a window.

Check the roof for areas that may need resealed. Snow should not be allowed to accumulate on the roof. The action of thawing and freezing could cause damage to vents and other items attached to the roof.

If the unit is stored uncovered, it is necessary to close roof vents, windows and door tightly to prevent moisture from entering the unit.

INTERIOR: The interior requires little preparation for winter storage. All appliances, both electrical and LP Gas should be turned off. Make sure that the LP Gas tanks are also turned off. All electricity going into the unit should be disconnected. It is recommended that you disconnect your 12-volt system. This will stop any drain on the battery caused by your LP detector and/or optional CO detector while unit is in storage.

Since air circulation is virtually eliminated when the trailer is totally closed, the following suggestions listed below will help to reduce musty odors, mold and excessive moisture:

1. Leave the door open on your refrigerator. Be sure to remove all food items.
2. Spread out your upholstery so that air can reach all portions.
3. Open all cabinet doors and drawers.
4. Place one or more containers of moisture gathering beads in the trailer. This will help to reduce condensation and excessive accumulation of moisture inside the trailer.

Winterize the water system by following instructions provided above.

EXTERIOR MAINTENANCE

The trailer has been engineered to provide many years of trouble-free service and a minimum amount of maintenance. The following guidelines indicate items that require periodic maintenance and inspection.

EXTERIOR FINISH: The exterior structure of the trailer is made of fiberglass or metal. Metal, rubber and plastic components are also attached to or part of the exterior structure of the trailer. The finish on those materials is durable but not indestructible. Any material or finish will deteriorate in time. Exposure to the elements and airborne pollutants can chemically alter the composition of many materials causing dulling and fading to the finish. Most often these changes due to weathering are on the surface and do not affect the strength of the exterior components of the trailer.

SIGNS OF WEATHERING:

1. Chalking. The surface finish has broken down into a fine powder that will usually wash off.
2. Fading. The color of the finish has changed. This can be caused by chemicals, pollutants in the air, ultraviolet rays of the sun, or by changes in the pigments used in the

- finish. Some fading is normal over a period of time.
3. Yellowing. Usually caused by chemical changes in the material and pigments.

Routine maintenance is the best way to insure against these cosmetic changes on the exterior components. Routinely wash and wax the exterior of the trailer thoroughly to deter surface deterioration. Wash the exterior on a monthly basis. Never use strong solvents or harsh abrasives to clean exterior surfaces. Wax the exterior at least once a year, following the instructions given by the manufacturer of the wax. **IMPORTANT:** Some cleaners and waxes are recommended for use only on certain types of surfaces. Note the recommended uses supplied by the manufacturer.

More frequent washing and waxing reduces the exterior streaking caused from the accumulation of dirt particles and other pollutants setting for prolonged periods on the roof and sides of the coach.

WINDOWS, DOORS, VENTS AND LOCKS: Keep moving parts of windows and latches adjusted and maintained. Lubricate the windows with a light oil or powdered graphite at least once a year. Periodically check and tighten the screws holding the windows in place. Lubricate lock sets, hinges on entry door and exterior storage compartments at least annually with oil or silicone lubricant. Check the weather sealant. If the trailer is exposed to salt air or winter road chemicals, more frequent lubrication will be required.

SEALANT RENEWAL: The adhesives and sealants used in the construction of the trailer were developed to remain waterproof under sustained effects of weather and vibration. However, even the finest materials eventually dry out and lose their effectiveness under constant heat of the sun and attack by other elements. This section outlines the procedures that you must follow to maintain the weatherproof integrity of your trailer. Leak damage caused by neglect could affect warranty.

DOORS AND WINDOWS: Inspect the sealants around windows and doors at least every six months. If any of the following defects are evident, the affected areas must be resealed:

1. Sealant cracked or peeling
2. Voids in sealant
3. Shrunken or separated sealant

Upon inspection you find that it is necessary to reseal, remove the excess sealant with a plastic scraper and clean all areas to be resealed with mineral spirits and clean rags.

WARNING: MINERAL SPIRITS IS A FLAMMABLE LIQUID. USE EXTREME CARE WHEN HANDLING AND USING. DO NOT EXPOSE TO OPEN FLAME, SPARKS OR SMOKING MATERIALS. DO NOT USE IN UNVENTILATED AREAS.

Make sure that all areas to be resealed are absolutely dry before new sealant is applied.

Your dealer can inspect the trailer, and complete the resealing if necessary. The dealer can also recommend the appropriate sealants to use if you prefer to do this job yourself. **IMPORTANT:** Always use the recommended sealants.

RUBBER ROOF:

1. Cleaning. For normal cleaning, standard household detergents can be used to wash the rubber roof material. Rinse thoroughly after cleaning. Be sure to keep the sidewalls wet

to reduce streaking when cleaning roof.

2. Care. The rubber material itself does not require annual coatings or additional sealants. Periodic washing with soap and water is all that is required.
3. Inspect the roof at least every six months in areas that have sealant added (around roof vents, tv antenna, etc.) and any seams or patch in the roofing material. If resealing is necessary, use the same type of sealant as originally applied. See your dealer for approved sealants.
4. The rubber roof material can be cut by sharp objects. Use caution when loading sharp articles on the roof. If you add accessories or new equipment on the roof, be sure the installer is qualified to work on the rubber roof material.
5. Repair kits are available through your dealer if the roof material is cut or torn. Remember that the roof requires special adhesives and material.
6. Additional information regarding the roof material is provided by the manufacturer.

INTERIOR MAINTENANCE

UPHOLSTERY AND WINDOW TREATMENT: Professionally clean only. Frequent vacuuming or light brushing between periods of professional cleaning will prevent accumulation of dirt. Use of water based or detergent based cleaners may cause shrinking. Water stains may become permanent.

WARNING: DO NOT USE LACQUER THINNER, NAIL POLISH REMOVER, CARBON TETRACHLORIDE, GASOLINE, OR NAPHTHA FOR ANY CLEANING PURPOSE. THESE PRODUCTS MAY CAUSE DAMAGE TO THE MATERIAL BEING CLEANED AND ARE HIGHLY FLAMMABLE OR POISONOUS.

WALL AND CEILING PANELS: The paneling and ceiling of your trailer may be any of several finishes and textures. Never use harsh detergents or abrasive cleaners on walls or ceilings. Most surfaces will clean with a soft cloth moistened with a mild liquid detergent in warm water. Do not use large amounts of water which could saturate the material.

FLOORS AND CARPETING: Vinyl flooring requires only washing and periodic waxing. Vacuum carpeting regularly and clean with a quality carpet cleaner.

TUB AND SHOWER: For routine cleaning use a non-abrasive cleaner. Never use harsh detergents or abrasive cleaners. Never use a razor blade or steel wool to clean surfaces.

WOOD PRODUCTS: Remove dust with a clean, slightly damp cloth. Apply a quality furniture polish and buff with a soft, dry cloth. Never use harsh detergents and solvents.

LAMINATE COUNTER TOPS AND TABLE: Use a mild dishwashing liquid with warm water for cleaning all laminate surfaces. Use a soft cloth to wash and dry the laminate surface. Abrasive cleaners or steel wool will damage the surface.

GENERAL INFORMATION AND HELPFUL HINTS

NOTICE TO CAMPERS:

- Campers, trailers and 5th-wheels need adequate ventilation at all times.
- Make sure that the fresh air vent to the heating system is not blocked. Be careful not to pile snow over the fresh air vent. Do not seal windows, doors or ventilator openings with tape.
- If heavy snowfall piles up around vents on roof, the snow should be removed.
- When using LP Gas appliances provide adequate ventilation. Check burners for proper combustion. Your attention to these details at all times is the only way to assure the safety of your family.
- Never use an unvented LP Gas fired heater for additional heat in the trailer.
- Never try to interchange LP Gas or natural gas in a heater unless the appliance has been specifically approved or converted for the change by a licensed technician.
- Always shut off the LP Gas supply while in route and routinely check connections in the line.
- Always check to make sure that the generator--optional equipment--has adequate ventilation and that vents and exhaust have not been blocked by snow or other objects.
- Be sure to have your generator--optional equipment--checked at least once a year to insure the unit is in proper running order and exhaust system is free of leaks and damage.

SYMPTOMS OF CARBON MONOXIDE POISONING:

Tight feeling across the forehead, headache, chest tightness, nausea, vertigo, and general malaise. Such symptoms are too often ignored or blamed on the "flu bug." The nervous system may be so suddenly and completely impaired that there is no chance to escape. **PREVENTION IS THE BEST PLAN.**

Be sure your CO Detector is functioning properly anytime a generator is in use.

EMERGENCY LIFESAVING TREATMENT FOR CARBON MONOXIDE POISONING:

1. Remove the victim to fresh, but not cold air.
2. Administer artificial respiration if breathing has stopped or is difficult.
3. Contact a physician as soon as possible.
4. Administer oxygen if available.
5. Assist the circulation by applying blankets to keep the victim warm and by rubbing the victim's arms and legs.
6. Never let a CO victim get up and walk around until a doctor says the victim is recovered. Exercise speeds up the attack of CO on the heart.

CONDENSATION AND YOUR RV: Condensation is a process where molecules of moisture in the air (water vapor) condense into droplets of water. Condensation is a natural process. You may not be able to eliminate condensation completely but you can control the effects of condensation inside your RV.

Several factors can affect the amount of condensation that may occur in your RV. As you know moisture in the air comes from many sources. What is surprising, though, is the amount.

Cooking for a family of four can add up to eight pounds (one gallon) of water per day into the air. Washing the dishes can add another pound.

An average shower adds between one-quarter to one-half pound of water into the air.

Mopping and rinsing an 8'x 10' area of floor space could add up to two and one-half pounds of water.

When you wash ten pounds of clothing and spin-dry in the washing machine, that load of clothes still contains about ten pounds of water. That amount of water is released into the air as the clothes dry.

People and animals contribute a large amount of water to the air. One person can add up to four pounds of water into the air per day through breathing and perspiration. Multiply that amount by a family of four and that is almost twelve pounds of water per day.

Use of humidifiers, vaporizing inhalers or similar mechanisms will also add excessive water to the air.

Your RV has gas appliances. When gas is burned, carbon dioxide, nitrogen and water are given off into the air.

The average RV is much smaller than your home plus your RV is built with much tighter construction than your home. Your home has cracks and spaces that allow moisture to escape while your RV is tightly sealed.

You can reduce moisture inside your RV by running your power vent fans when cooking and bathing. When possible dry wet clothing outside. When drying clothing inside your unit you can run your power vent fans, open ceiling vents or windows to force the excess moisture outside.

Partially open one or more roof vents or windows to provide circulation of air in your RV. In cold weather this will increase the operation of your furnace but it will reduce or eliminate condensation inside your RV.

If you use your RV for a long period of time during cold weather, leave cabinet and closet doors partially open to warm and ventilate storage compartments. The airflow will warm the exterior wall surface and prevent possible ice formation. Limit the articles in each storage compartment because tightly packed storage areas will restrict air flow.

Keep your shades up and curtains open as much as possible to allow air flow around windows. Do not seal windows or doors tightly with tape as this will restrict further the air flow in your RV.

Dehumidifying appliances are available and recommended. Use of a dehumidifier will reduce the amount of outside air needed for ventilation of your RV. A dehumidifier is very effective for removing excess moisture from the air inside your RV--especially during continuous use.

Keeping a window partially open while on the road can also help to ventilate your RV and help to reduce the moisture that has collected inside your RV before traveling.

Regular maintenance such as keeping registers and furnace blower clean and unobstructed and cleaning your furnace air filters will help promote good air circulation in your RV.

Your first indication of excessive moisture in the air could be foggy windows. In very cold weather frost or ice can form on the inside of the glass. Excessive moisture could be indicated by water dripping from walls, ceilings or fixtures. When this happens you might think that your RV has a leak. That is usually not the case. Excessive water can penetrate almost any material. It will go through walls, floor covering, plywood, paint. The water that gets absorbed into these materials can cause warping, mildew, paint chipping and rotting. This type of damage can be invisible and costly to repair so it is extremely important for you to take steps to control excessive moisture buildup inside your RV.

Problems caused by excessive moisture and condensation will not be covered under your warranty.

Your new RV has been specifically designed for your camping and traveling requirements. Understanding that condensation is a natural occurrence which can be controlled will help you and your family to utilize your RV for your family's camping needs and provide many years of camping enjoyment.

DUST SEEPAGE: Travel over unpaved, dusty rough roads inevitably generates quantities of dust which has a way of leaking into trailers. The problem can be reduced by partially opening a roof vent. This will help keep the dust out. From time to time it is advisable to adjust the striker plate on the entry door. Road vibration can cause the entry door to get out of adjustment. This could allow access for dust and moisture to leak into the trailer.

SAFE DRIVING TIPS: Your trailer has been designed by NORTHWOOD to be driven at legal highway speeds without unusual handling characteristics. Driving with a recreational vehicle may be a new experience for you. The following tips are outlined to assist you.

TRAVELING SPEED: Reasonable vehicle speed is probably the greatest factor in safe, pleasant traveling with your trailer. With experience you will develop the special driving skills needed for safe traveling.

WARNING: TRAVELING AT MODERATE SPEEDS ALLOWS FOR ADVERSE HIGHWAY AND WIND CONDITIONS. INCREASED SPEED REDUCES STABILITY OF THE TOW VEHICLE AND TRAILER AND THE SAFE MANEUVERING AND STOPPING ABILITY OF YOUR TOW VEHICLE.

WARNING: DO NOT USE A CRUISE CONTROL OR AUTOMATIC SPEED REGULATING DEVICE WHEN TOWING A TRAILER.

WARNING: DO NOT ATTEMPT TO STOP TRAILER SWAYING BY QUICK STEERING CHANGES OR BY FORCEFULLY APPLYING THE TOW VEHICLE BRAKES. IT IS BEST TO USE THE MANUAL LEVER LOCATED ON YOUR BRAKE CONTROL.

OTHER TRAVELING TIPS:

Try the trailer out on short trips to get the feel of how the tow vehicle handles with the trailer loaded. Backing a vehicle while using only mirrors may appear difficult, but with a little practice you will become proficient at backing with your mirrors. You can also have someone stand to the rear to guide you. The best place to practice is a large empty parking lot.

Before departing on a trip check your routes. Remember that some tunnels prohibit travel trailers and campers with LP gas systems.

- Before traveling make sure all cabinet doors are closed and drawers and loose objects are secure.
- Be sure that you have traffic clearance before pulling out from the curb. Apply power slowly and evenly avoiding over acceleration when starting from curb or other stopping point.
- Watch for dips or obstructions in the road which could cause damage to the undercarriage of your tow vehicle or trailer.

- **Drive at moderate speeds, particularly in traffic and adverse weather conditions. Gusty or strong wind conditions can radically and violently change the stability of your tow vehicle and trailer. Take precautions when passing another vehicle, especially trucks. Be aware that another vehicle passing you can also radically change the stability of your tow vehicle and trailer. When in doubt, slow down or pull off of the road especially in adverse weather conditions.**

Safe stopping depends upon brakes, speed, road surface, tire condition, and many other factors. Be sure to keep a safe distance between you and the traffic ahead of you. Remember that the weight of the trailer adds an additional stopping burden to your tow vehicle. Allow extra distance for passing and stopping.

Do not travel with full holding tanks. Empty holding tanks before traveling. Be aware that full holding tanks can radically change the weight distribution and balance of the trailer and will alter the towability of your unit—particularly in rear bath models. Any radical weight distribution change in your trailer will alter how your tow vehicle handles.

Instruct your family on what to do in case of a fire. Hold fire drills periodically. Practice using the emergency exits. Maintain proper charge in the fire extinguisher.

Insure that the LP gas detector provided with your unit is in proper working condition.

Keep a well-stocked first-aid kit handy.

Become familiar with the position of tow vehicle and trailer in traffic. Be cautious when maneuvering to allow for the length and width of the vehicle. Always allow extra room to corner and to change lanes. Learn to use the side mirrors to view the road behind. Check your mirrors often.

- The engine and transmission on your tow vehicle may overheat when you are driving in hilly or mountainous terrain. If this happens, pull off to the side of the road and allow your engine to idle while your transmission is in neutral. This will help return engine and transmission temperature to normal.
- Emergency braking may, under certain road conditions, cause a skid. Turn the front wheels of the tow vehicle in the direction of the skid to counteract the effects of the skid. Never lock the brakes on the tow vehicle. Apply the breaks lightly until the skid is reduced.
- When traveling off the highway in the country or mountains you must be careful of overhanging tree limbs and other overhead or side obstacles. Light branches will brush aside, but heavier branches and limbs may cause damage to the roof or sidewall of your trailer. Consider your roof height, vents, jacks, antennas, air conditioner and other equipment attached to the roof or side of your tow vehicle and trailer when you are calculating clearance.
- Avoid parking too close to the curb as signs, telephone poles and other obstructions can cause problems.
- Watch for overhead and side clearance at drive-in restaurants and gas stations or other drive-in areas so you do not crunch the side or roof of your trailer and tow vehicle.
- Watch for sharply crowned roads which can tip your unit into obstructions when parking close

to a curb or roadside.

SAFETY CONSIDERATIONS:

The following list contains important safety checks to review and keep in mind while traveling:

1. Never overload your vehicle. Improper load distribution can cause serious handling problems on the road.
2. Never attempt to repair or alter a gas or electric appliance. Always consult an authorized and qualified service agency or technician.
3. Portable fuel-burning equipment, including wood and charcoal grills and stoves, cannot be used inside the trailer. The use of this equipment inside the trailer could cause fire and/or asphyxiation.
4. Do not bring or store LP Gas containers, gasoline or other flammable liquids inside the trailer. Doing so could risk the danger of fire or explosion.

SAFETY REGULATIONS REGARDING LP GAS SYSTEMS AND LP GAS APPLIANCES

The manufacturer of this recreational vehicle is required to furnish the following consumer information as provided by the National Fire Protection Association and the American National Standards Institute. The information and warnings found here may also be found in other sections of this Owner's Manual. See sections titled "**LPG SYSTEM**" and "**APPLIANCES**" for other safety and operating information.

WARNING

LP GAS CONTAINERS SHALL NOT BE PLACED OR STORED INSIDE THE VEHICLE. LP GAS CONTAINERS ARE EQUIPPED WITH SAFETY DEVICES WHICH RELIEVE EXCESSIVE PRESSURE BY DISCHARGING GAS TO THE ATMOSPHERE.

WARNING

IT IS NOT SAFE TO USE COOKING APPLIANCES FOR COMFORT HEATING, COOKING APPLIANCES NEED FRESH AIR FOR SAFE OPERATION. BEFORE OPERATION:

1. OPEN OVERHEAD VENT OR TURN ON EXHAUST FAN **AND**
2. OPEN WINDOW.

THIS WARNING LABEL HAS BEEN LOCATED IN THE COOKING AREA TO REMIND YOU TO PROVIDE AN ADEQUATE SUPPLY OF FRESH AIR FOR COMBUSTION. UNLIKE HOMES, THE AMOUNT OF OXYGEN SUPPLY IS LIMITED DUE TO THE SIZE OF THE RECREATIONAL VEHICLE. PROPER VENTILATION WHEN USING THE COOKING APPLIANCE(S) WILL AVOID DANGERS OF ASPHYXIATION. IT IS ESPECIALLY IMPORTANT THAT COOKING APPLIANCES NOT BE USED FOR COMFORT HEATING AS THE DANGER OF ASPHYXIATION IS GREATER WHEN THE APPLIANCE IS USED FOR LONG PERIODS OF TIME.

WARNING

PORTABLE FUEL-BURNING EQUIPMENT, INCLUDING WOOD AND CHARCOAL GRILLS AND STOVES, CANNOT BE USED INSIDE THIS RECREATIONAL VEHICLE. THE USE OF THIS EQUIPMENT INSIDE THE RECREATIONAL VEHICLE MAY CAUSE FIRES OR ASPHYXIATION.

WARNING

DO NOT BRING OR STORE LP GAS CONTAINERS, GASOLINE, OR OTHER FLAMMABLE LIQUIDS INSIDE THE VEHICLE BECAUSE A FIRE OR EXPLOSION MAY RESULT.

A warning label has been located near the LP Gas container. This label reads: DO NOT FILL CONTAINER(S) TO MORE THAN 80 PERCENT OF CAPACITY.

Overfilling the LP Gas container can result in uncontrolled gas flow which can cause fire or explosion. A properly filled container will contain approximately 80 percent of its volume as liquid LP Gas.

The following label has been placed in the vehicle near the range:

IF YOU SMELL GAS:

1. Extinguish any open flames, pilot lights and all smoking materials.
2. Do not touch electrical switches.
3. Shut off the gas supply at the tank valve(s) or gas supply connection.
4. Open doors and other ventilating openings.
5. Leave the area until odor clears.
6. Have the gas system checked and leakage source corrected before using again.

LP Gas regulators must always be installed with the diaphragm vent facing downward. Regulators that are not in compartments have been equipped with a protective cover. Make sure that the regulator vent faces downward and the cover is kept in place to minimize vent blockage which could result in excessive gas pressure causing fire or explosion.

PRODUCT IDENTIFICATION INFORMATION

Please take a few minutes to fill out the following information for future reference:

YOUR NAME	
TRAILER MODEL	
SERIAL NUMBER	
DATE PURCHASED	
DEALER NAME	
DEALER ADDRESS	
DEALER PHONE	
INSURANCE POLICY NO.	
INSURANCE AGENT	
AGENT'S PHONE NO.	

KEY NUMBERS

RANGE/OVEN

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

REFRIGERATOR

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

FURNACE

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

WATER HEATER

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

AIR CONDITIONER (OPTIONAL)

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

MICROWAVE OVEN (OPTIONAL)

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

AM/FM TAPE PLAYER OR CD PLAYER (OPTIONAL)

MANUFACTURER _____
 MODEL _____
 SERIAL NO. _____

OTHER

OTHER

OTHER

OTHER

OTHER

APPLIANCE AND PRODUCT OWNER'S MANUALS

OWNER'S MANUAL

Consider this owner's manual a permanent part of your trailer. Keep it with the trailer at all times. If you sell the unit, the new owner will appreciate the operating, safety and maintenance information contained in this owner's manual. Also keep all manuals and tags furnished with the appliances and other equipment installed in your trailer.

IMPORTANT NOTICE:

THIS OWNER'S MANUAL IS OF A GENERAL NATURE ONLY AND DOES NOT COVER EVERY ASPECT OF ALL MODELS OF TRAVEL TRAILERS AND 5TH WHEEL TRAILERS MANUFACTURED BY NORTHWOOD MANUFACTURING.

DUE TO ONGOING DESIGN DEVELOPMENT AT NORTHWOOD, IT IS POSSIBLE THAT RECENT PRODUCT CHANGES MAY NOT BE INCLUDED IN THIS OWNER'S MANUAL. THIS MANUAL IS INTENDED AS A GUIDE ONLY AND IN NO WAY EXTENDS THE RESPONSIBILITY OF NORTHWOOD BEYOND THE WARRANTY PRINTED IN THIS MANUAL.

ALTERING OR MODIFYING YOUR TRAVEL TRAILER OR 5TH WHEEL TRAILER

WARNING:

IF YOU PLAN ON MAKING ANY ALTERATIONS OR MODIFICATIONS TO YOUR TRAILER, CHECK WITH YOUR DEALER OR CALL THE FACTORY BEFORE GETTING STARTED. EVEN WHEN DOING SOMETHING THAT SEEMS SIMPLE, THE POTENTIAL HAZARD OF A DRILL, SCREW OR NAIL PENETRATING AN UNSEEN LP GAS LINE OR ELECTRICAL CIRCUIT MIGHT BE AVOIDED BY CHECKING WITH TECHNICAL SUPPORT BEFORE YOU START. DOUBLE CHECK TO MAKE SURE THAT ANY ALTERATIONS OR MODIFICATIONS THAT YOU PLAN TO DO TO YOUR TRAILER WILL NOT VOID YOUR WARRANTY.

PERIODIC MAINTENANCE CHECK LIST

Check	Function Required	Daily	Weekly	Every 3,000 Miles or 6 Months	Every 6,000 Miles or 12 Months
Trailer brakes	Test that they are functioning properly	X			
Air pressure	Inflate tires to manufacturer's specifications	X			
Lug bolts or Nuts (1)	Tighten to proper torque specifications			X	
Breakaway switch	Test switch operation, inspect connections			X	
Breakaway battery	Maintain charge, inspect connections		X		
Wheel rims	Inspect for dents, damage, or out of round			X	
Brake shoes (2)	Test brake drag and adjust if required			X	
Brake magnets	Inspect for uneven wear				X
Wheel bearings and cups	Inspect for wear or damage and lubricate				X
Hub / drum	Inspect for heavy scoring or wear				X
Seals	Inspect for heavy scoring or wear				X
Shackle links	Visually inspect for wear or bends				X
Equalizers	Visually inspect for wear or bends				X
Hangers	Visually inspect welds and bolt tightness				X
Springs	Visually inspect for broken, separated, or flattened (loss of camber) springs				X
Slide out room	Check slide out room function & sealing		X		

(1) Tighten wheel bolts or nuts every 50 miles for the first 200 miles and after every change in wheel mounting.

(2) Adjust brakes after first 200 miles, then at above intervals.

SERVICE CHART

SERVICE TO BE PERFORMED

SERVICE INTERVAL

Description	Each Trip or Weekly	1,000 Miles or 30 Days	2,500 Miles or 90 Days	5,000 Miles or 6 Months	10,000 Miles or Yearly
Pack wheel bearings					X
Inspect brakes					X
Inspect safety chains	X				
Inspect brake wiring	X				
Inspect tires	X				
Inspect hitch components	X				
Lubricate locks					X
Lubricate coupler latch & socket		X			
Lubricate hinges					X
Inspect & clean vents					X
Torque lug nuts		X			
Sanitize water tank (if trailer has been stored)			X		
Clean drapes & interior fabrics					
Clean battery cables & terminals, check fluid levels			X		
Inspect suspension					X
Check all seams & openings & reseal as needed				X	
Check water system components					X
Balance tires (after 1st 1,000 miles; as req. thereafter)		X			
Complete LPG system check & pressure check					X
Visually inspect exposed LPG system components (BEFORE EACH USE)	X				
Check generator (if equipped) exhaust system (BEFORE EACH USE)	X				

TWO YEAR WARRANTY
FOR TRAVEL TRAILERS AND 5TH-WHEELS MANUFACTURED BY NORTHWOOD MANUFACTURING
SOLD IN THE UNITED STATES AND CANADA

COVERAGE PROVIDED

Your new travel trailer/5th-wheel (coach), including the structure, plumbing, heating, and electrical systems, and all appliances and equipment installed by the manufacturer, is warranted under normal use to be free from manufacturing defects in material and workmanship.

This warranty extends to the first retail purchaser and his transferee(s) and begins on the date of original retail delivery or the date the coach is first placed into service as a rental, commercial or demonstrator coach (whichever occurs first). This warranty extends for a period of two years from such date. Written notice of defects must be given to the selling dealer or the manufacturer not later than ten (10) days after the expiration of the applicable warranty. Warranty repairs, if required, will be made without charge after your coach is taken to the dealer or manufacturing plant location.

OWNER'S OBLIGATIONS

The owner is responsible for normal maintenance as described in the Owner's Manual; however, minor adjustments (such as adjustments to the interior or exterior doors, LP regulator pressure, cabinet latches, TV antenna control, etc.) will be performed by the dealer during the first 90 days of warranty coverage. Thereafter, such adjustments are the responsibility of the owner as normal maintenance unless required as a direct result of repair or replacement of a defective part under this warranty.

DEALER'S OBLIGATIONS

By agreement with the manufacturer, the dealer is obligated to maintain the coach prior to retail sale, to perform a detailed pre-delivery inspection and to repair or replace any parts necessary to correct defects in material or workmanship.

WHEN A DEALER DOES NOT RESOLVE A PROBLEM

If the dealer is unable or unwilling to resolve a problem which the owner is convinced is covered by this warranty, he should contact NORTHWOOD MANUFACTURING at the address listed below and provide the manufacturer with a description in writing of the problem and attempts made to resolve it.

MANUFACTURER'S OBLIGATIONS

Upon receipt of notice of a claim which the dealer was unable or unwilling to resolve, NORTHWOOD MANUFACTURING will repair or replace any parts necessary to correct defects in material or workmanship, or will take other appropriate action as may be required.

WHAT IS NOT COVERED BY THIS WARRANTY

THIS WARRANTY DOES NOT COVER THE FOLLOWING:

1. Tires and batteries, which are covered by the separate warranties of the respective manufacturers of these components.
2. Damage caused by or related to:
 - A. Accidents, misuse or negligence
 - B. Failure to comply with instructions contained in the Owner's Manual
 - C. Alteration or modification of the coach.
 - D. Environmental conditions (salt, hail, chemicals in the atmosphere, etc.)
3. Normal deterioration due to wear or exposure, i.e., fading of fabrics, drapes, carpet wear, etc.
4. Normal maintenance and service items such as light bulbs, fuses, lubricants, etc.
5. Extra expenses such as transportation to and from dealer or manufacturing plant location, loss of time, loss of pay, loss of use of the coach, inconvenience, commercial loss, towing charges, bus fares, vehicle rental, incidental charges such as telephone calls or lodging bills, or other incidental or consequential damages.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

Dealers or any other persons are not authorized to make modifications to this warranty, any additional statements concerning this warranty, whether oral or written are not the responsibility of the manufacturer.

BRAND NAME _____ MODEL _____ SERIAL NO. _____

PHYSICAL ADDRESSES:

59948 Downs Road
La Grande, OR 97850
Telephone: 541-962-6274

380 Bataille Drive
Winchester, VA 22601
Telephone: 540-542-6140

MAILING ADDRESSES:

PO Box 3359
La Grande, OR 97850
Fax: 541-962-6217

PO Box 2630
Winchester, VA 22604
Fax: 540-542-6146